


HOW TO USE

- 1** Open Label Holder, place label roll, push down Bottom Lever to open.




CLEANING STUCK LABEL

Unscrew 2 screws. Easily remove stuck label by solvent for strong adhesive.



- 2** Insert label sideways under transparent Label Pressor, turn it back onto Bottom Cover, then close Label Holder.



- 3** Close Bottom Cover while pushing it, then lock it with Hook turning forwards to the reverse directions of an arrow


NOTICE

1. Unnecessary to make slit or slot on backing paper for feeding.
2. Film with less than 50 μ m thickness is unacceptable.
3. Use only die-cut labels.
4. A cotton-swab moistened with **ALCOHOL**, is recommended to wipe adhesive from Mecha-Sensor.

NV030, NV060, NV100
Instruction Manual

START International
www.startinternational.com

- 4** Cut backing paper, pulling it downwards carefully as arrow indicates.
- 5** Pull machine toward you at the same speed with gripping motion.



SPECIFICATIONS

MODEL	LABEL SIZE (mm)		MAX. OUTSIDE DIAMETER (mm)
	STROKE	WIDTH	
30	20-60	20-30	100
60	20-60	25-60	100
100	20-60	55-100	100

Please contact us if your shape labels seem difficult to dispense.
We reserve the right to change specifications without notice for improvement.