


## HOW TO USE

- 1** Open Label Holder, place label roll, push down Bottom Lever to open.




### CLEANING STUCK LABEL

Unscrew 2 screws. Easily remove stuck label by solvent for strong adhesive.



- 2** Insert label sideways under transparent Label Pressor, turn it back onto Bottom Cover, then close Label Holder.



- 3** Close Bottom Cover while pushing it, then lock it with Hook turning forwards to the reverse directions of an arrow


### NOTICE

1. Unnecessary to make slit or slot on backing paper for feeding.
2. Film with less than 50 $\mu$ m thickness is unacceptable.
3. Use only die-cut labels.
4. A cotton-swab moistened with **ALCOHOL**, is recommended to wipe adhesive from Mecha-Sensor.

**NV030, NV060, NV100**  
**Instruction Manual**

**START International**  
[www.startinternational.com](http://www.startinternational.com)

- 4** Cut backing paper, pulling it downwards carefully as arrow indicates.
- 5** Pull machine toward you at the same speed with gripping motion.



### SPECIFICATIONS

MODEL	LABEL SIZE (mm)		MAX. OUTSIDE DIAMETER (mm)
	STROKE	WIDTH	
30	20-60	20-30	100
60	20-60	25-60	100
100	20-60	55-100	100

Please contact us if your shape labels seem difficult to dispense.  
We reserve the right to change specifications without notice for improvement.